

### Studwork/Pocket Assembly/Wall Thickness

	Studwork	Frame Assembly	Finished wall Thickness	Plasterboard EACH SIDE		Jamb needed	Notes
				On Pocket	Rest of Wall		
W O O D  S T U D	63mm	75mm	100mm	One 12.5mm layer	One 6mm layer One 12.5mm layer	100mm	Alt. attach 12.5mm ply to one side and treat as 75mm frame
	70mm	75mm	100mm	One 12.5mm layer	One 15mm layer	100mm	
	75mm	75mm	100mm	One 12.5mm layer	One 12.5mm layer	100mm	
	89mm	100mm	125mm	One 12.5mm layer	One 6mm layer One 12.5mm layer	125mm	Alt. attach 12.5mm ply to one side and treat as 100mm frame
	95mm	100mm	125mm	One 12.5mm layer	One 15mm layer	125mm	
	100mm	100mm	125mm	One 12.5mm layer	One 12.5mm layer	125mm	
M E T A L  S T U D	70mm	75mm	100mm	One 12.5mm layer	One 15mm layer	100mm	
	70mm	75mm	125mm	Two 12.5mm layer	One 15mm layer One 12.5mm layer	125mm	Using the second rebate on jamb
	95mm	100mm	125mm	One 12.5mm layer	One 15mm layer	125mm	
	95mm	100mm	150mm	Two 12.5mm layer	One 15mm layer One 12.5mm layer	125mm	Using an L profile architrave